

Flamenco®

Pearlescent and Iridescent Pigments for Color Cosmetics
and Personal Care Products

Technical Information

November 2016

Flamenco pigments are used to create lustrous or opalescent effects in all types of cosmetics and personal care products. They are available in a wide range of colors, as well as white, and in a variety of grades providing many degrees of luster and differing effects.

Flamenco Pearl Pigments

Flamenco Pearl white effect enhancing pigments are titanium dioxide-coated mica platelets. They are offered in a range of particle sizes that have varying degrees of luster.

- The Satin Pearl grade combines relatively low luster with excellent coverage. It has superior tactile properties and a translucent, satiny-white effect that is both soft and luminous.
- The Ultra Silk grade creates a smooth, silky effect while offering excellent coverage and superior whiteness.
- The Satina and Velvet grades offer many of the same properties as Ultra Silk, but with increasing levels of luster.
- The Superpearl grade offers excellent transparency, which can help reduce the milky look that occurs with pearlescent effects in medium-dark and deep tones. Its brilliance allows formulators to use less pigment without compromising end product luster.
- The Ultra Sparkle grade combines transparency with a silvery-white sparkle effect.
- The Supreme Sparkle grade gives a very sparkly look that is ideal for all types of personal care and color cosmetic products.

Flamenco Pearl Pigments – Typical Properties

FLAMENCO GRADE*	COLOR/EFFECT	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
				Lb/ft ³	g/100cm ³
Pearl 110C	Transparent white	9 - 44µm	2.9	11	18
Super Pearl 120C	Transparent white	10 - 44µm	3.2	10	16
Satina 120T	White	6 - 37µm	3.3	10	16
Velvet 120V	Moderately white	5 - 22µm	3.4	10	16
Winter Sparkle 130Q	White high sparkle	29 - 130µm	2.8	16	26
Ultra Silk 2500	Very white	4 - 20µm	3.3	9	14
Satin Pearl 3500	Satiny white	2 - 11µm	3.5	9	14
Ultra Sparkle 4500	Transparent silvery sparkle	15 - 82µm	3.1	9	14
Supreme Sparkle 8500	Bright white sparkle	28 - 108µm	2.9	9	14

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Interference Colors

Flamenco colors use thin, precisely controlled films of titanium dioxide on mica to separate white light into its component parts and produce dual colors, one by reflection one by transmission, that then appear as iridescence. They are available in a range of particle sizes. The small particle sizes produce more subtle luminous effects, while the larger ones impart higher levels of shimmer and sparkle.

Flamenco Interference Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Gold 220C	gold	blue	8 - 44µm	3.0	15	24
Orange 320C	orange	blue-green	8 - 44µm	3.1	13	21
Red 420C	red	green	9 - 44µm	3.1	15	24
Violet 520C	violet	yellow-green	9 - 45µm	3.1	15	24
Blue 620C	blue	yellow	9 - 44µm	3.1	14	23
Green 820C	green	red	8 - 43µm	3.2	16	26

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Super Colors

Flamenco Super Colors are intermediate particle size interference pigments that can be used alone or combined with other colorants to create novel effects in all types of cosmetics and personal care products. The effects possible with these highly colored interference pigments provide unique highlights that are striking in any color background.

Flamenco Super Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Super Gold 230Z	gold	blue	9 - 37µm	3.2	13	21
Super Red 430Z	red	green	9 - 37µm	3.2	13	21
Super Violet 530Z	violet	yellow-green	9 - 37µm	3.3	15	25
Super Blue 630Z	blue	yellow	9 - 37µm	3.3	16	26

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Summit Colors

Flamenco Summit Colors are intermediate particle size interference effect pigments that feature increased chromaticity at the reflection angle as well as high color purity and clarity.

Flamenco Summit colors can create dramatic visual effects in all types of cosmetic and personal care products. The turquoise and aqua grades offer formulators exciting expanded color space opportunities. These products possess attributes that create cleaner shades, more saturated color and stronger angle-dependent interference effects.

Flamenco Summit Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Summit Gold Y30D	gold	blue	11 - 34µm	3.4	16	25
Summit Red R30D	red	green	11 - 39µm	3.4	18	29
Summit Blue B30D	blue	yellow	11 - 39µm	3.5	15	25
Summit Aqua A80H	aqua	yellow	10 - 34µm	2.9	16	26
Summit Turquoise T30D	turquoise	yellow-red	7 - 35µm	3.7	24	39
Summit Green G30D	green	red	8 - 36µm	3.7	24	38

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Silk Colors

Fine particle size Flamenco Silk Colors provide subtle luster for cosmetics and personal care formulations. They have the smallest particle size of any cosmetic grade interference colors, and provide excellent coverage and a fine, satin appearance. When used with other colorants, Flamenco Silk Colors create complex color interplay.

Flamenco Silk Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Silk Gold 230M	gold	blue	4 - 16µm	3.4	15	24
Silk Orange 330M	orange	blue-green	4 - 16µm	3.4	15	24
Silk Red 430M	red	green	4 - 16µm	3.5	16	26
Silk Violet 530M	violet	yellow-green	4 - 18µm	3.5	17	28
Silk Blue 630M	blue	yellow	4 - 17µm	3.5	20	32
Silk Green 830M	green	red	4 - 18µm	3.6	22	35

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Sparkle Colors

Flamenco Sparkle colors are large particle size effect pigments, available in a full range of interference colors that add shimmer and glitter to all types of cosmetics and personal care products. These dispersible powders retain high color intensity even though they are composed of larger sized particles.

Sparkle colors are ideal for formulations that call for complex color interplay and a glittery appearance. When used with other colorants, they create a spectrum of striking highlights.

Flamenco Sparkle Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Sparkle Gold 220J	gold	blue	21 - 77µm	2.9	16	26
Sparkle Orange 320J	orange	blue-green	19 - 76µm	3.1	16	26
Sparkle Red 420J	red	green	21 - 77µm	3.1	16	26
Sparkle Violet 520J	violet	yellow-green	21 - 77µm	3.1	16	26
Sparkle Blue 620J	blue	yellow	19 - 71µm	3.1	16	26
Sparkle Green 820J	green	red	15 - 74µm	3.1	16	26
Summer Gold 230Q	gold	blue	25 - 126µm	2.7	22	35

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Flamenco Twilight Colors

Flamenco Twilight colors can be used in all types of cosmetics and personal care products to create intense, dark interference highlights against any background. They create an antiqued look, and when combined with other colorants a wide range of complex colors.

Flamenco Twilight Colors – Typical Properties

FLAMENCO GRADE*	REFLECTION COLOR	TRANSMISSION COLOR	PARTICLE SIZE (µm) RANGE**	DENSITY (Kg/L)	APPROX. BULK DENSITY***	
					Lb/ft ³	g/100cm ³
Twilight Red 430ZB	red	green	9 - 36µm	3.4	17	27

* Please refer to individual product specification sheets for certifiable product specifications

** The particle size results will vary depending on the light scattering instrument used. The values listed (as % by weight) are the results using a Malvern Mastersizer. 80% of particles are found between the ranges noted in the table.

*** Determined by ASTM Method D-716-86

Applications

Formulating Guidelines

Flamenco pigments are chemically stable under conditions normally encountered in cosmetic and personal care formulation product and use. However, all grades should be tested in potential formulations before commercialization in order to determine if performance will be acceptable

Since regulations change over time, we recommend that appropriate use of each colorant be confirmed against each region's current cosmetic regulations.

Physical and Chemical Properties

Solubility

Flamenco pigments are inorganic and therefore insoluble in water.

pH

The pH of these products is measured by adding 4 grams of the pigment into 96 mL of water. This value can be found on the specification sheet.

Specifications

For product specifications refer to the respective specification sheet (separate document) for each Flamenco product.

The color additive components in the products identified in this data sheet meet the applicable FDA (21 CFR Part 73), EU Cosmetic Regulation EC/1223/2009 (Annex IV, including EC-231-2012 requirements), Japan MHW, Korean Cosmetics Colorants Standard, and China's Cosmetic Safety and Technical Standard (2015 version) specifications and purity requirements.

Microbial status for Flamenco products:

Total aerobic bacteria	<100 CFU/g max.
Yeast & mold	<100 CFU/g max.
Gram-negative bacteria	absent in 10g
E. coli	absent in 10g
Pseudomonas aeruginosa	absent in 10g
Staphylococcus aureus	absent in 10g

Storage

Flamenco pigments have storage stability of at least 10 years from the date of manufacture, provided that they are stored in unopened original containers, protected from light, and under normal conditions of temperature and humidity.

Safety Data Sheet

A Safety Data Sheet for each Flamenco pigment is available.

Further Product Ranges

Bi-Lite® Bismuth Oxychloride/Mica Pigments
Cellini® Colors
Chione™ Pigments
Chroma-Lite® Colors
Cloisonné® Colors
Duochrome® Iridescent Colors
Flamenco® Pearlescent and Iridescent Pigments
Gemtone® Colors
Mearlite® and Biju® Ultra Bismuth Oxychloride Pigments
Mearmica® Specialty Performance Mica
MultiReflections™ Iridescent Pigments
Pearl-Glo® Bismuth Oxychloride Pigments
Reflections™ Pearlescent and Iridescent Pigments and Colors
Reflections™ Dimensions Pearlescent and Iridescent Pigments and Colors
Reflections™ MultiDimensions Color Changing Pigments
Timica® Luster Pigments

Appendix – Flamenco Product Compositions

Table 1: Flamenco Pearl Pigments

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Pearl 110C - INCI Name: Mica (and) Titanium Dioxide				
Mica	65 – 75 %	77019	12001-26-2	310-127-6
TiO ₂	25 – 35 %	77891	13463-67-7	236-675-5
Flamenco Superpearl 120C - INCI Name: Mica (and) Titanium Dioxide				
Mica	67 – 77 %	77019	12001-26-2	310-127-6
TiO ₂	23 – 33 %	77891	13463-67-7	236-675-5
Flamenco Satina 120T - INCI Name: Mica (and) Titanium Dioxide				
Mica	63 – 73 %	77019	12001-26-2	310-127-6
TiO ₂	27 – 37 %	77891	13463-67-7	236-675-5
Flamenco Velvet 120V - INCI Name: Mica (and) Titanium Dioxide				
Mica	58 – 68 %	77019	12001-26-2	310-127-6
TiO ₂	32 – 42 %	77891	13463-67-7	236-675-5
Flamenco Winter Sparkle 130Q - INCI Name: Mica (and) Titanium Dioxide				
Mica	85 – 95 %	77019	12001-26-2	310-127-6
TiO ₂	5 – 15 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Ultra Silk 2500 - INCI Name: Mica (and) Titanium Dioxide				
Mica	61 – 67 %	77019	12001-26-2	310-127-6
TiO ₂	33 – 39 %	77891	13463-67-7	236-675-5
Flamenco Satin Pearl 3500 - INCI Name: Mica (and) Titanium Dioxide				
Mica	50 – 60 %	77019	12001-26-2	310-127-6
TiO ₂	40 – 50 %	77891	13463-67-7	236-675-5
Flamenco Ultra Sparkle 4500 - INCI Name: Mica (and) Titanium Dioxide				
Mica	80 – 90 %	77019	12001-26-2	310-127-6
TiO ₂	10 – 20 %	77891	13463-67-7	236-675-5
Flamenco Supreme Sparkle 8500 - INCI Name: Mica (and) Titanium Dioxide				
Mica	85 – 95 %	77019	12001-26-2	310-127-6
TiO ₂	5 – 15 %	77891	13463-67-7	236-675-5

Table 2: Flamenco Interference Pigments

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Gold 220C - INCI Name: Mica (and) Titanium Dioxide				
Mica	58 – 68 %	77019	12001-26-2	310-127-6
TiO ₂	32 – 42 %	77891	13463-67-7	236-675-5

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Orange 320C - INCI Name: Mica (and) Titanium Dioxide				
Mica	52 – 67 %	77019	12001-26-2	310-127-6
TiO ₂	33 – 48 %	77891	13463-67-7	236-675-5
Flamenco Red 420C - INCI Name: Mica (and) Titanium Dioxide				
Mica	47 – 63 %	77019	12001-26-2	310-127-6
TiO ₂	37 – 53 %	77891	13463-67-7	236-675-5
Flamenco Violet 520C - INCI Name: Mica (and) Titanium Dioxide				
Mica	49 – 60 %	77019	12001-26-2	310-127-6
TiO ₂	40 – 51 %	77891	13463-67-7	236-675-5
Flamenco Blue 620C - INCI Name: Mica (and) Titanium Dioxide				
Mica	46 – 59 %	77019	12001-26-2	310-127-6
TiO ₂	41 – 54 %	77891	13463-67-7	236-675-5
Flamenco Green 820C - INCI Name: Mica (and) Titanium Dioxide				
Mica	37 – 53 %	77019	12001-26-2	310-127-6
TiO ₂	47 – 63 %	77891	13463-67-7	236-675-5

Table 3: Flamenco Super Colors

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Super Gold 230Z - INCI Name: Mica (and) Titanium Dioxide				
Mica	53 – 64 %	77019	12001-26-2	310-127-6
TiO ₂	36 – 46 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Super Red 430Z - INCI Name: Mica (and) Titanium Dioxide				
Mica	46 – 58 %	77019	12001-26-2	310-127-6
TiO ₂	42 – 53 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Super Violet 530Z - INCI Name: Mica (and) Titanium Dioxide				
Mica	42 – 55 %	77019	12001-26-2	310-127-6
TiO ₂	45 – 57 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Super Blue 630Z - INCI Name: Mica (and) Titanium Dioxide				
Mica	40 – 51 %	77019	12001-26-2	310-127-6
TiO ₂	49 – 59 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0

Table 4: Flamenco Summit colors

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Summit Turquoise T30D - INCI Name: Mica (and) Titanium Dioxide				
Mica	32.3 – 41.3 %	77019	12001-26-2	310-127-6
TiO ₂	58.7 – 66.7 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Summit Gold Y30D - INCI Name: Mica (and) Titanium Dioxide				
Mica	57.1 – 64.1 %	77019	12001-26-2	310-127-6
TiO ₂	35.9 – 41.9 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Summit Red R30D - INCI Name: Mica (and) Titanium Dioxide				
Mica	52.4 – 59.4 %	77019	12001-26-2	310-127-6
TiO ₂	40.6 – 46.6 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Summit Blue B30D - INCI Name: Mica (and) Titanium Dioxide				
Mica	47.2 – 54.2 %	77019	12001-26-2	310-127-6
TiO ₂	45.8 – 51.8 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Summit Aqua A80H - INCI Name: Mica (and) Titanium Dioxide (and) Silica				
Mica	40 – 58 %	77019	12001-26-2	310-127-6
TiO ₂	35 – 46 %	77891	13463-67-7	236-675-5
SiO ₂	6 – 12 %	-	7631-86-9	231-545-4
SnO ₂	1.1 – 2 %	-	18282-10-5	242-159-0
Flamenco Summit Green G30D - INCI Name: Mica (and) Titanium Dioxide				
Mica	29.3 – 38.3 %	77019	12001-26-2	310-127-6
TiO ₂	61.7 – 69.7 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0

Table 5: Flamenco Silk colors

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Silk Gold 230M - INCI Name: Mica (and) Titanium Dioxide				
Mica	29 – 45 %	77019	12001-26-2	310-127-6
TiO ₂	55 – 70 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Silk Orange 330M - INCI Name: Mica (and) Titanium Dioxide				
Mica	23 – 41 %	77019	12001-26-2	310-127-6
TiO ₂	59 – 66 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Silk Red 430M - INCI Name: Mica (and) Titanium Dioxide				
Mica	21 – 39 %	77019	12001-26-2	310-127-6
TiO ₂	61 – 78 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Silk Violet 530M - INCI Name: Mica (and) Titanium Dioxide				
Mica	18 – 36 %	77019	12001-26-2	310-127-6
TiO ₂	64 – 81 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Silk Blue 630M - INCI Name: Mica (and) Titanium Dioxide				
Mica	15 – 33 %	77019	12001-26-2	310-127-6
TiO ₂	67– 84 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0
Flamenco Silk Green 830M - INCI Name: Mica (and) Titanium Dioxide				
Mica	13 – 33 %	77019	12001-26-2	310-127-6
TiO ₂	67– 86 %	77891	13463-67-7	236-675-5
SnO ₂	< 1 %	-	18282-10-5	242-159-0

Table 6: Flamenco Sparkle colors

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Sparkle Gold 220J - INCI Name: Mica (and) Titanium Dioxide				
Mica	71 – 83 %	77019	12001-26-2	310-127-6
TiO ₂	17 – 29 %	77891	13463-67-7	236-675-5
Flamenco Sparkle Orange 320J - INCI Name: Mica (and) Titanium Dioxide				
Mica	68 – 80 %	77019	12001-26-2	310-127-6
TiO ₂	20 – 32 %	77891	13463-67-7	236-675-5
Flamenco Sparkle Red 420J - INCI Name: Mica (and) Titanium Dioxide				
Mica	67 – 79 %	77019	12001-26-2	310-127-6
TiO ₂	21 – 33 %	77891	13463-67-7	236-675-5
Flamenco Sparkle Violet 520J - INCI Name: Mica (and) Titanium Dioxide				
Mica	66 – 78 %	77019	12001-26-2	310-127-6
TiO ₂	22 – 34 %	77891	13463-67-7	236-675-5

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Sparkle Blue 620J - INCI Name: Mica (and) Titanium Dioxide				
Mica	63 – 75 %	77019	12001-26-2	310-127-6
TiO ₂	25 – 37 %	77891	13463-67-7	236-675-5
Flamenco Sparkle Green 820J - INCI Name: Mica (and) Titanium Dioxide				
Mica	58 – 70 %	77019	12001-26-2	310-127-6
TiO ₂	30 – 42 %	77891	13463-67-7	236-675-5
Flamenco Summer Gold 230Q - INCI Name: Mica (and) Titanium Dioxide				
Mica	76 – 96 %	77019	12001-26-2	310-127-6
TiO ₂	3 – 23 %	77891	13463-67-7	236-675-5
SnO ₂	0.2 – 1.0 %	-	18282-10-5	242-159-0

Table 7: Flamenco Twilight colors

Colorant	By Weight	CI No.	CAS No.	EINECS No.
Flamenco Twilight Red 430ZB - INCI Name: Mica (and) Titanium Dioxide (and) Iron Oxides				
Mica	34 – 55 %	77019	12001-26-2	310-127-6
TiO ₂	34 – 46 %	77891	13463-67-7	236-675-5
Fe ₃ O ₄	11 - 19 %	77499	1317-61-9	215-277-5
Fe ₂ O ₃	< 2 %	77491	1309-37-1	215-168-2
SnO ₂	< 1 %	-	18282-10-5	242-159-0

Product Range

Product	PRD-No.
Flamenco® Blue 620C	30322390
Flamenco® Gold 220C	30322391
Flamenco® Green 820C	30322392
Flamenco® Orange 320C	30322393
Flamenco® Pearl 110C	30322394
Flamenco® Red 420C	30322402
Flamenco® Satin Pearl 3500	30322407
Flamenco® Satina 120T	30322410
Flamenco® Silk Blue 630M	30551290
Flamenco® Silk Gold 230M	30516184
Flamenco® Silk Green 830M	30552870
Flamenco® Silk Orange 330M	30551289
Flamenco® Silk Red 430M	30551291
Flamenco® Silk Violet 530M	30523438

Product Range continued

Product	PRD-No.
Flamenco® Sparkle Blue 620J	30322461
Flamenco® Sparkle Gold 220J	30322462
Flamenco® Sparkle Green 820J	30322463
Flamenco® Sparkle Orange 320J	30322464
Flamenco® Sparkle Red 420J	30322465
Flamenco® Sparkle Violet 520J	30322466
Flamenco® Summer Gold 230Q	30523092
Flamenco® Summit Aqua A80H	30655735
Flamenco® Summit Blue B30D	30322467
Flamenco® Summit Gold Y30D	30322468
Flamenco® Summit Green G30D	30322469
Flamenco® Summit Red R30D	30322470
Flamenco® Summit Turquoise T30D	30322526
Flamenco® Super Blue 630Z	30322527
Flamenco® Super Gold 230Z	30322528
Flamenco® Super Pearl 120C	30322533
Flamenco® Super Red 430Z	30322531
Flamenco® Super Violet 530Z	30322532
Flamenco® Supreme Sparkle 8500	30322534
Flamenco® Twilight Red 430ZB	30322548
Flamenco® Ultra Silk 2500	30322550
Flamenco® Ultra Sparkle 4500	30302057
Flamenco® Velvet 120V	30322551
Flamenco® Violet 520C	30322552
Flamenco® Winter Sparkle 130Q	30322553

Contacts

Asia Pacific

BASF Colors & Effects Shanghai Ltd.
No 300, Jiang Xin Sha Road
200137 Shanghai
China

North America

BASF Colors & Effects USA LLC
24710 West Eleven Mile Road
Southfield, MI 48034
USA

Europe

BASF Colors & Effects GmbH
An der Rheinschanze 1
67059 Ludwigshafen
Germany

South America

BASF S/A
Av. das Nações Unidas, 14171
Crystal Tower 11th floor,
Morumbi 04538-132, São Paulo
Brazil

Visit our website: www.colors-effects.basf.com

This document, or any answers or information provided herein by BASF, does not constitute a legally binding obligation of BASF. While the descriptions, designs, data and information contained herein are presented in good faith and believed to be accurate, it is provided for your guidance only. Because many factors may affect processing or application/use, we recommend that you make tests to determine the suitability of a product for your particular purpose prior to use. It does not relieve our customers from the obligation to perform a full inspection of the products upon delivery or any other obligation. NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE REGARDING PRODUCTS DESCRIBED OR DESIGNS, DATA OR INFORMATION SET FORTH, OR THAT THE PRODUCTS, DESIGNS, DATA OR INFORMATION MAY BE USED WITHOUT INFRINGING THE INTELLECTUAL PROPERTY RIGHTS OF OTHERS. IN NO CASE SHALL THE DESCRIPTIONS, INFORMATION, DATA OR DESIGNS PROVIDED BE CONSIDERED A PART OF OUR TERMS AND CONDITIONS OF SALE.

® = Registered trademark of BASF

™ = Trademark of BASF